

ASSEMBLY INSTRUCTIONS – EY07086

Creative Castle

PLEASE NOTE THAT ASSEMBLY WILL NEED AT LEAST TWO ADULTS.

1. CHECK ALL PARTS ARE PRESENT.
2. SELECT SUITABLE LEVEL POSITION.
3. STAND UP THE LARGE PANEL WITH ARROW SLITS. Fig 1
4. OFFER UP THE SMALL PANEL WITHOUT THE DOOR UP TO THE LARGE PANEL, AND FIX TOGETHER USING FIVE X 100MM SCREWS THROUGH THE MARKED PRE DRILLED HOLES. Fig 2, 3, 4 & 5
5. OFFER UP THE LARGE PANEL WITHOUT THE ARROW SLITS TO THE SMALL SOLID PANEL AND FIX WITH FIVE X 100MM SCREWS, THROUGH THE MARKED PRE DRILLED HOLES. Fig 6, 7, 8 & 9
6. SLIDE THE FLOOR INTO POSITION IN BETWEEN BOTH LARGE PANELS AND UP TO THE SMALL SOLID PANEL. Fig 10
7. PLACE THE DOOR PANEL IN BETWEEN BOTH LARGE PANELS, ENSURING THE FRONT PANEL IS TIGHT UP TO THE FLOOR. FIX TOGETHER USING TEN X 100MM SCREWS, FIVE IN EACH LARGE PANEL INTO THE FRONT PANEL, THROUGH THE MARKED PRE DRILLED HOLES. Fig 11, 12 & 13
8. WHEN ALL THE SIDE PANELS ARE FIXED TOGETHER AND THE FLOOR IS SAT IN THE CORRECT POSITION, FROM UNDER THE PRODUCT, FIX THE FLOOR TO ALL SIDE PANELS USING THIRTY TWO 60MM SCREWS THROUGH MARKED PRE DRILLED HOLES. (SIX SCREWS INTO BOTH SMALL PANELS AND TEN SCREWS INTO BOTH LARGE PANELS). Fig 14 & 15
9. OFFER UP THE FRONT RAMP ONTO THE BATTEN OF TIMBER UNDER THE DOOR, PLACE INTO POSITION AND FIX USING TWO X 100MM SCREWS (ONE EACH SIDE), AND TWO X 60MM SCREWS THROUGH TOP OF THE RAMP INTO TIMBER BATTON, THROUGH THE MARKED PRE DRILLED HOLES. Fig 16, 17, 18 & 19
10. Finished product – Fig 20

Parts List:

- THIRTY FOUR X 60MM FIXING SCREWS
- TWENTY TWO X 100MM FIXING SCREWS

Tools Required

- DRILL OR SCREWDRIVER.



ASSEMBLY INSTRUCTIONS – EY07086

Creative Castle



Fig 1.



Fig 2.



Fig 3.



Fig 4.



Fig 5.



Fig 6.



Fig 7.



Fig 8.



Fig 9.



ASSEMBLY INSTRUCTIONS – EY07086

Creative Castle



Fig 10.



Fig 11.



Fig 12.



Fig 13.



Fig 14.



Fig 15.

ASSEMBLY INSTRUCTIONS – EY07086

Creative Castle



Fig 16.



Fig 17.



Fig 18.



Fig 19.



Fig 20.

