

## ASSEMBLY INSTRUCTIONS – MEDIUM ADVENTURE UNIT WITH BRIDGE

**PLEASE NOTE THAT ASSEMBLY WILL NEED AT LEAST TWO ADULTS.**

1. CHECK ALL PARTS ARE PRESENT.
2. SELECT SUITABLE POSITION ON FLAT, LEVEL GROUND FOR THE ADVENTURE UNIT TO BE BASED.
3. PLACE ONE OF THE ISLANDS INTO POSITION. THEN, PLACE THE OTHER ISLAND OPPOSITE. PLEASE MAKE SURE THE ISLANDS ARE POSITIONED AS PER PICTURE. **(Fig 1)**
4. PLACE THE FOOTBRIDGE INTO POSITION BETWEEN THE TWO ISLANDS. THERE IS A LIP ON EACH ISLAND FOR SUPPORT. **(Fig 2)**
5. USING 6 X 80MM SCREWS DRILL THE UNDERNEATH OF THE BRIDGE TO EACH ISLAND USING THE PRE-DRILLED HOLES – 3 SCREWS ON EACH SIDE. **(Fig 3)**
6. PLACE BOTH SIDE PANELS INTO POSITION TO FORM THE BRIDGE. MAKE SURE THE PANELS ARE FLUSH. **(Fig 4)**
7. DRILL ONE SIDE PANEL INTO POSITION USING THE PRE-DRILLED HOLES. 4 X 60MM SCREWS DOWN. 4 X 80MM SCREWS TO THE LEFT. 4 X 80MM SCREWS TO THE RIGHT. REPEAT ON BOTH PANELS **(Fig 5,6)**
8. LIFT ONE OF THE RAMPS INTO POSITION (CHOICE IS YOURS). SCREW INTO POSITION AT BOTH SIDES USING 2 X 80MM SCREWS THROUGH PRE-DRILED HOLES. REPEAT FOR THE SECOND RAMP. **(Fig 8, 9,)**
10. FINISHED PRODUCT. **(Fig 10)**



**Fig 1**



**Fig 2**



**Fig 3**

## ASSEMBLY INSTRUCTIONS – MEDIUM ADVENTURE UNIT WITH BRIDGE



**Fig 4**



**Fig 5**



**Fig 6**



**Fig 8**



**Fig 9**



**Fig 10**

## ASSEMBLY INSTRUCTIONS – MEDIUM ADVENTURE UNIT WITH BRIDGE

### Fixings & Tools Required

1 x Screwdriver

30 x 80mm Screws

16 x 60mm Screws