

## **Assembly instructions for the Physical Clamber Unit – EL45944**

**This product will require two people to assemble.**

### **Fitting Kit**

4 x 100mm Wood Screws

### **Tools Required**

Cordless Drill/Screwdriver

1. Place both ramps on either side of the unit so they lock into place with the small timber beams on each end.
2. Screw 2 x 100mm screws into each side of both ramps where the screw holes are pre-drilled (the same each side)