Illuminated Writing Boards

Technical Support

Please visit www.tts-group.co.uk for the latest product information.

Email feedback@tts-group.co.uk for technical support.

TTS Group Ltd.

Park Lane Business Park

Kirkby-in-Ashfield

Nottinghamshire,

NG17 9GU, UK.

Freephone: 0800 318686 Freefax: 0800 137525

WARNING: Do not dispose of this product in household

waste. Hand it over to a collection point for

recycling electronic appliances.

WARNING: Not suitable for children under 36 months due

to small parts – choking hazard.

Made in China, on behalf of TTS Group Ltd.



TTS is proud to be part of RM plc



Important information

Please retain the information in this User Guide for future reference.

Please read all instructions fully before using.

To clean, wipe the surface with a clean damp cloth. Do not allow the product to come into contact with water or other liquids.

Keep the product away from direct sunlight and heat. If your product malfunctions please switch it off and then back on again to reset it.

Battery Precautions

- Illuminated Writing Boards are powered by Lithium battery packs which are not user replaceable.
- Do not attempt to remove the battery packs.
 This product is supplied with a 5V 1A international adaptor.

Contents of Pack

- 4 x Illuminated Writing Boards
- Docking Station
- International Charging Adaptor
- User Guide

Know Your Illuminated Writing Boards



Using Your Illuminated Writing Boards

To switch the Writing Board on, move the slide switch to the ON position.

The first colour when switched on will be Red. To cycle through the seven colours press the button on the front of the Writing Board once for each colour change. When the colour red is reached again it will automatically cycle through the colours in sequence. Pressing the button again whilst in automatic sequence mode will turn the writing board off into standby mode.

Always switch your Illuminated Writing Board off using the on/off switch to preserve the battery life.

Recharging Your Illuminated Writing Boards

The Writing Board will flash red to show that the batteries are low and the product needs charging.

Insert the adaptor cable into the charging socket at the side of the docking station.

Place the Writing Boards into the docking station ensuring they are fully connected. The Writing Boards will flash red to show they are charging.

It may take up to 4 hours to fully charge if the battery has been fully discharged.

The Writing Board will light solid Green when fully charged.

Only charge your Writing Boards in the docking station and only use the battery charger provided.

Once fully charged the Writing Boards will have approximately 10-12 hours life if used continuously.

Troubleshooting

Problem	Solution
Writing Board will not	Ensure the switch is in the
	"ON" position.
	Recharge the Writing Board by
	placing in the docking station.

Warranty & Support

This product is provided with a one year warranty for problems found during normal usage. Mistreating the Writing Boards or opening the unit will invalidate this warranty.