

Our Giant Dark Den has been designed to help you create a sensory area inside your setting without the need for a separate sensory room. We've put these step-by-step instructions together to help you put it up quickly and easily. You might need another person to help with assembly.

1



Make sure you've got all the parts!

- 8 x short poles
- 8 x short poles (with connector)
- 4 x long poles
- 4 x long poles (with connector)
- 8 x 3-way corner connectors
- 1 x Giant Dark Den Cover

It might help to separate them as we have.


2



Join the poles with connectors to those without. Large poles go with large poles, short with short.




3




Take the combined short poles and feed through the sleeves on the Dark Den. We found it best to find the flap and start from the bottom. Repeat with three other short poles.

4



Use the corner connectors to join up the poles to form a square as shown. This will form the base of your den.



5



Repeat steps 3 & 4 to form the top of the den. You should now have two squares.

6



Insert the long poles through the sleeves on the sides and join the two squares together.

7



Your finished Giant Dark Den awaits! Why not make a giant den frame by assembling without the cover?

EY01100

Giant Dark Den



GB

AGE: 3+ IMPORTANT: The assembly and storage of your product should always be carried out by a responsible adult.

IMPORTANT: Children should be supervised at all times!

WARNING: KEEP AWAY FROM FIRE!

Made in China

Wipe with a damp cloth to clean

3 YEARS +

