EY07295 Outdoor Play Corner Cottage



Two persons required for assembly

This unit is designed for use outdoors and on a flat surface.1m should be kept clear around the edge of the playhouse to ensure safe play.

An Adult should ALWAYS SUPERVISE PLAY!


Please retain this information and our contact details for future reference.

Siting

- •The structure should be placed on a level and even surface
- •The structure should be in a corner of a play area
- •Consider anchoring in exposed sites



Tools





•Driver Bit - T40

Access equipment

Sealant Dispenser

13mm socket/spanner



Fixings

6x70mm - 26

M8x110m bolts - 6

6x50mm - 3

6x90mm - 4

6x60mm - 8

Maintenance

- •The structures should be regularly inspected and the bolts and screws tightened, if necessary.
- The longevity of your playhouse will be enhanced by the annually application of a high quality wood preservative.
- Care should be taken to avoid damaging the timber during any gardening (mowing, strimming etc) to avoid breaking the preservative envelope.





Back panels x2





Front Head Beam



Not Shown -Finial

3

Central Roof bars x 3



Side Roof Bars x2





x 4

















9 10









•Bolt through side frame bars
•M8x110 - 4


•Place second central roof panel in place and ensure frame matches as shown
•Bolt through central frame bars
•M8x110 - 2

TTS Group Ltd - Park Lane Business Park, Kirby-in-Ashfield, Nottinghamshire, NG17 9GU, United Kingdom

Fasten through roof frame into front head beam •6x70 - 3

www.tts-shopping.com

Tel: 0800 318686





17 18 19 20





