



Easi-Headphones

Headphones that will stand
the test of time!

Warranty & Support

This product is provided with a one year warranty for problems found during normal usage. Mistreating the Easi-Headphones or opening the unit will invalidate this warranty.

All out of warranty repairs will be subject to a replacement fee.

Technical Support

Please visit www.tts-group.co.uk for the latest product information.

Email feedback@tts-group.co.uk for technical support.

TTS Group Ltd.
Park Lane Business Park
Kirkby-in-Ashfield
Nottinghamshire,
NG17 9GU, UK.
Freephone: 0800 318686 Freefax: 0800 137525



Easi-Headphones

WARNING: Do not dispose of this product in household waste. Hand it over to a collection point for recycling electronic appliances.

WARNING! Not suitable for children under 36 months due to small parts – choking hazard. Made in China, on behalf of the TTS Group Ltd.



TTS Group Ltd.,
Park Lane Business Park,
Kirkby-in-Ashfield,
Nottinghamshire,
NG17 9GU, UK

TTS Product Code:
EL00356

USER GUIDE

www.tts-shopping.com



Easi-Headphones

Important Information

Easi-Headphones are designed to be robust and are ideal for use in educational settings. The replaceable ear cushions have been designed to cover the whole ear to minimise outside noise and to increase comfort and the quick release cable can be removed for storage or replaced. The headband is not only adjustable, but also very flexible, helping to limit damage. Please read all instructions carefully before using and retain for future reference.



Contents of pack

- EasiHeadphonest
- Audio connection cable
- User Guide

Care of your Easi-Headphones

- If necessary, wipe the Easi-Headphones gently with a clean damp cloth.
- Keep the Easi-Headphones away from direct sunlight and heat.
- Do not allow the Easi-Headphones to come into contact with water or other liquids.

Connecting Easi-Headphones

Easi-Headphones are shipped with a stereoaudio lead to connect between the Easi-Headphones and your audio source. The cable is symmetrical so it does not matter which end is connected.



The headphone cushions can be removed and replaced with new ones. Please note that what is removed and replaced is the complete earpiece assembly including the plastic clips and the material that holds the foam on.



- To remove: Grip the ear pad firmly and rotate anticlockwise 1/8th turn. The whole ear pad assembly can then be removed
- To replace: Locate the lugs on the ear pad assembly into the headphones, and then rotate clockwise 1/8th turn until it clicks.

Safety Standards

Easi-Headphones have been designed to meet the following standards: RoHS, CE, EMC.

Specification	
Impedance:	32ohms
Frequency response:	100 – 16kHz \pm 3dB
Max power rating:	30mW
Magnet:	12.5 x 1.5mm NdFeB
Output SPL	119dB at 1kHz, 1mW (IEC318)