

## **ASSEMBLY INSTRUCTIONS – LARGE ADVENTURE UNIT EL47046**

**PLEASE NOTE THAT ASSEMBLY WILL NEED AT LEAST TWO ADULTS.**

1. CHECK ALL PARTS ARE PRESENT.
2. SELECT SUITABLE POSITION ON FLAT, LEVEL GROUND FOR THE ADVENTURE UNIT TO BE BASED.
3. PLACE ONE OF THE ISLANDS INTO POSITION. THEN, PLACE THE OTHER ISLAND OPPOSITE. PLEASE MAKE SURE THE ISLANDS ARE POSITIONED AS PER PICTURE. **(Fig 1, 2)**
4. PLACE THE FOOTBRIDGE INTO POSITION BETWEEN THE TWO ISLANDS. THERE IS A LIP ON EACH ISLAND FOR SUPPORT. **(Fig 3)**
5. USING 6 X 80MM SCREWS DRILL THE UNDERNEATH OF THE BRIDGE TO EACH ISLAND USING THE PRE-DRILLED HOLES – 3 SCREWS ON EACH SIDE. **(Fig 4,5)**
6. PLACE BOTH SIDE PANELS INTO POSITION TO FORM THE TUNNEL. MAKE SURE THE PANELS ARE FLUSH. **(Fig 6,7)**
7. DRILL ONE SIDE PANEL INTO POSITION USING THE PRE-DRILLED HOLES. 4 X 60MM SCREWS DOWN. 4 X 80MM SCREWS TO THE LEFT. 4 X 80MM SCREWS TO THE RIGHT. REPEAT ON BOTH PANELS **(Fig 8,9)**
8. LIFT THE ROOF OF THE TUNNEL INTO POSITION. SCREW THE ROOF TO THE SIDE PANELS USING 4 X 60MM SCREWS ON EACH SIDE. 8 IN TOTAL. **(Fig 10,11)**
9. PLACE INTO POSITION THE THIRD AND FINAL ISLAND. LIFT INTO PLACE THE CURVED BRIDGE AND PLACE ON THE TWO TIMBER LIPS ON EACH ISLAND. **(Fig 12.13)**
10. USING 6 X 80MM SCREWS DRILL THE UNDERNEATH OF THE BRIDGE TO EACH ISLAND USING THE PRE-DRILLED HOLES – 3 SCREWS ON EACH SIDE **(Fig 14)**
11. DRILL ONE SIDE PANEL INTO POSITION USING THE PRE-DRILLED HOLES. 6 X 80MM SCREWS INTO ONE SIDE. REPEAT ON OTHER PANEL **(Fig 15,16).**
12. PLACE ALL RAMPS INTO POSITION. YOU ARE WELCOME TO MIX AND MATCH AS YOU PLEASE. SCREW INTO POSITION THROUGH PRE-DRILLED HOLES USING 2 X 80MM SCREWS ON EACH SIDE OF THE RAMPS **(Fig.17,18)**

## ASSEMBLY INSTRUCTIONS – LARGE ADVENTURE UNIT EL47046

### 13. FINAL PRODUCT (Fig 19)




Fig 1



Fig 2



Fig 3



Fig 4



Fig 5




Fig 6



Fig 7



Fig 8

## ASSEMBLY INSTRUCTIONS – LARGE ADVENTURE UNIT EL47046



Fig 9



Fig 10



Fig 11



Fig 12



Fig 13



Fig 14



Fig 15



Fig 16



Fig 17



Fig 18



## ASSEMBLY INSTRUCTIONS – LARGE ADVENTURE UNIT EL47046



### Fixings & Tools Required

- 1 x Screwdriver
- 46 x 80mm Screws
- 16 x 60mm Screws